

Quick Pclix LT Programming Guide



To enter Programming Mode turn OFF your Pclix LT, Hold down red FIRE button, turn ON your Pclix LT, wait for 3 RED flashes to finish, release red Fire button. v1.7

LF Dial	User Option	RT Dial and Steps for Programming Sequence
0 0 0	Split Second Off/On	Set RT Dial 0=OFF 1=ON, Enter Programming Mode, release FIRE button, after 4 Green flashes turn OFF your Pclix LT.
1 0 0	Delay Start Off/On	Set RT Dial 0=OFF 1=ON, Enter Programming Mode, release FIRE button, after 4 Green flashes turn OFF your Pclix LT.
2	Set Delay Start Length	Enter Programming Mode, release Fire button, after 1 Green flash set the Hours, push Fire button, after 2 Green flashes set the Minutes, push FIRE button, after 3 Green flashes set the Seconds, push FIRE button, after 4 Green flashes turn OFF.
3 0 0	Image Count Off/On	Set RT Dial 0=OFF 1=ON, Enter Programming Mode, release FIRE button, after 4 Green flashes turn OFF your Pclix LT.
4	Set Image Count	Enter Programming Mode, release Fire button, after 2 Green flashes set the Thousands & Hundreds, push FIRE button, after 3 Green flashes set the Tens & Ones, push FIRE button, after 4 Green flashes turn OFF your Pclix LT. See Over ->

LF Dial	User Option	RT Dial and Steps for Programming Sequence
5 0 0	Bulb Option Off/On	Set RT Dial 0=OFF 1=ON, Enter Programming Mode, release FIRE button, after 4 Green flashes turn OFF your Pclix LT.
6	Set Bulb Length	Enter Programming Mode, release FIRE button, after 2 Green flashes set the Minutes, push FIRE button, after 3 Green flashes set the Seconds, push FIRE button, after 4 Green flashes turn OFF your Pclix LT.
7	Set Camera Model	Set the RT Dial to desired Camera Model 0-7 (see user manual for details), Enter Programming Mode, release FIRE button, after 4 Green flashes turn OFF your Pclix LT.
8	Not Used	If selected you will get an error warning.
9	Set User Intervals	Set RT Dial to a register from 0-9, Enter Programming Mode, after 1 Green flash set the Hours, push Fire button, after 2 Green flashes set the Minutes, push FIRE button, after 3 Green flashes set the Seconds, push FIRE button, after 4 Green flashes turn OFF your Pclix LT.

This Guide is meant to be a quick reference only, for detailed operating instructions for the Pclix LT please see your users manual or download it from our website.



www.pclix.com

copyright©2010 1017 Visual Effects Inc.

See Over ->